Réglage du seuil d'intervention I∆n

2 Sélection du calibre x1 / x10 / x100

① Setting intervention threshold **I**∆ n

2 Range selector x1 / x10 / x100

3 • **4** Signaling LED

I∆n

	0,03	0,05	0,075	0,1	0,15	0,2	0,3
x1	30mA	50mA	75mA	100mA	150mA	200mA	300mA
x10	300mA	500mA	750mA	1A	1,5A	2A	3A
x100	3A	5A	7,5A	10A	15A	20A	30A

Vérifier que la valeur d'intervention sélectionnée est compatible avec le seuil de sensibilité mini. du tore associé.

Check that selected intervention value matches the lowest sensibility detectable by the connected ring current transformer.

FRONT DESCRIPTION

3 • **4** Signalisation LED

On	″ Trip / Fail						
•	•	Manque de tension alimentation auxiliaire ou appareil défectueux Lack of auxiliary voltage supply or out of order meter					
*	•	Supervision • Supervision					
*	*	Alarme • Alarm					
*	• * • **	Interruption du raccordement tore-relais Connection breakdown between relay and ring current transformer					

LFD éteint LED off LED allumé LED on •*****•***** LED clignotant LED blinking

6 Touche de test

Permet de vérifier le fonctionnement tore-relais, commutation **LED Trip** allumée et commutation du relais.

Touche de Reset l'état du relais est actif jusqu'à ce que l'opérateur agisse sur la touche **RESET**.

Le réarmement ne pourra s'effectuer lorsque le courant de défaut mesuré : > 50% **I** Λ n

Sélection PF / AL.50%

PF = alarme (17-18-19) + signalisation POWER FAIL (60-61-62) Al.50% = alarme (17-18-19) + préalarme 50% **I**∆ n (60-61-62)

3 Sélection état du relais de sortie: Nd (norm. désexcité) sécurité négative -

Ne (norm. excité) sécurité positive. Le relais de préalarme est toujours normallement désexcité. Le relais POWER FAIL est toujours normallement excité.

Réglage de la temporisation
En réglant le seuil d'intervention sur la position 0,03 le délai d'intervention est automatiquement exclu, indépendamment de la position du sélecteur de

Pour sélectionner le seuil d'intervention **①** I∆ n = 30mA avec une intervention instantanée sélectionner 0,03 et assurez vous que le sélecteur 2

- Insertion (on) - exclusion (off) filtre pour les harmoniques.

En raccordant le filtre pour les harmoniques, le différentiel ne doit pas être utilisé pour la protection des personnes.

INSTRUCTIONS DE RACCORDEMENT

- La position de montage n'affecte en rien le bon fonctionnement de l'appareil.
- · Les opérations de réglage (seuil d'intervention, temporisation, etc.) doivent être effectués avec l'appareil hors tension.
- Suivre méthodiquement le schéma de raccordement : une erreur peut altérer le fonctionnement ou causer des dommages à l'appareil.
- Pour le fonctionnement optimum du système de protection différentielle, les recommandations suivantes doivent être respectées:
- Réduire autant que possible la distance entre le tore et le relais
- Utiliser des câbles de raccordement tore-relais blindés ou torsadés
- Fixed de placer les câbles de raccordement tore-relais parallèlement à des raccordements de puissance.
- Eviter d'installer le tore et le relais près d'une source de champ électromagnétique (gros transformateurs).
- Passer dans le tore uniquement un conduceur actif (des.**D1**)
- Si vous utilisez du câble blindé, l'armature doit être raccordée à la terre (des.D2)
- Assurez vous que le conducteur soit positionné au centre du tore (des.D3).

6 Test key

It allows to simulate alarm condition, LED Trip switching on and output

6 Reset key the alarm stays until the operator doesn't act on RESET key. Reset is not possible with persistent residual current: > 50% I Δ n.

Selector PF / AL.50%

PF = alarm (17-18-19) + POWER FAIL signaling (60-61-62) Al.50% = alarm (17-18-19) + pre-alarm $50\%\Delta$ n (60-61-62)

3 Switch for state of output relay: Nd (normally de-energised) negative security **Ne** (normally energised) positive security.

Pre-alarm relay is always normally de-energized. POWER FAIL relay is always normally energised

9 Setting intervention delay

Selecting the intervenction threshold on position 0,03 the intervention delay is automaticall excluded, independently of position of range selector, \mathbf{O} . To set intervention threshold \mathbf{O} $\mathbf{I}\Delta$ n = 30mA with instantaneous intervention, select 0,03 and make sure that selector $\mathbf{0}$ is on position x1.

1 Instantaneous display of earth leakage current (in % of selected I∆n value) On-off harmonic filter

By connecting the harmonic component filter, the differential must not be used to protect people.

WIRING INSTRUCTIONS


- Mounting position do not affect in any way the proper working.
 Setting operations (intervention threshold, delay time, etc.) must be carried out with non-fed meter.
- Please carefully follow the wiring diagram; an error in connecting the relay may give rise to irregular working or damages.
- Four full functional of the earth relay the following installation recommendation should be adopted.
- To reduce as much as possible the distance between ring current transformer
- To use only shielded or twisted cables for their connection
- To avoid in placing ring current transformer-relay connection cables parallelly to power wires
- To avoid in mounting ring current transformer and relay near sources of intense electromagnetic fields (big transformers).
- Pass active conductor only through toroid (draw D1)
- When using blind cable, ensure ground connection of armature (draw D2)

 Ensure the central positioning of conductor through toroid (draw D3).










Guide d'utilisation User's Guide

Cod. RD3B2





TORE FERME / CLOSED CORE					TORE OUVRANT / OPEN CORE							
	CODE CODE	PASSAGE DE CÂBLE Passing Cable	I∆n min ⁽¹⁾ A	In A	6In A		CODE CODE	PASSAGE DE CÂBLE PASSING CABLE	I∆n min ⁽¹⁾ A	In A	6In A	
	4021 1028	Ø 28	0,03	65	390		4021 221	Ø 110	0,5	250	1500	
	4021 1035	Ø 35	0,03	70	420		4021 221	5 Ø 150	0,5	250	1500	
	4021 1060	Ø 60	0,03	90	540		4021 223	0 Ø 300	1	630	3780	
	4021 1080	Ø 80	0,05	170	1020							
	4021 1105	Ø 110	0,1	250	1500							
	4021 1140	Ø 140	0,3	250	1500							

Diamètre: diamètre de l'ouverture interne du transformateur (passage câble/barre)

 $\mathbf{I}\Delta\,\mathbf{n}$ min: valeur mimum sélectionnable sur le relais différentiel afin d'éviter un déclenchement intempestif

In: courant nominal du switch

Les valeur spécifiées sont uniquement valables si les câbles sont positionnés au centre du transformateur

Ex. Comment choisir le bon transformateur pour un courant nominal

(ln) = 125A

Pour être conforme aux normes EN/IEC 60947-2 annexe M. utiliser un transformateur type 4021 1080

Courant In = 170A

Lorsque les courants transitoires sont faibles (< a 6ln), des transformateurs plus petits peuvent être utilisés, à condition que la formule suivant soit

6In (voir tableau)

-= surcharge max. admissible

Ex. En utilisant un transformateur 4021 1060 valeur 6In = 540A avec un switch de courant nominal In=125A

540A

Is (courant nominal du switch)

125A

La surcharge permanente admissible est de 4,32 fois le In du switch.

Diameter: internal hole of the transformer (bus bar and cable passage)

 $I\Delta$ n min: minimum value to be set on the Earth Leakage Relay in order to avoid unwanted tripping

In: rated current of the switch

The specified values are valid if the cables are positioned in the centre of the transformer

E.g. How to choose the correct transformer for a specific nominal current (In) = 125 A

To comply with the specification of the standard EN/IEC 60947-2 annex M, the type 4021 1080 should be used

Current In = 170A Current 6In = 1020A

Where the transients current are not so high, smaller transformers (< a 6ln) may be used provided that the following calculation is respected:

6In (see table)

= max overload permissible

Is (nominal current of the switch)

E.g. A 4021 1060 type with value 6In = 540A in conjunction with a switch of In=125A

125A


Permissible maximum overload is 4,32 times the In of the switch.

SECURITE NEGATIVE • NEGATIVE SECURITY

2400


400


SECURITE POSITIVE • POSITIVE SECURITY




Ø 210

4021 1210







SECURITE NEGATIVE • NEGATIVE SECURITY

AI.50%

SECURITE POSITIVE • POSITIVE SECURITY

